






M-12


RTV 150

INSTRUKCJA MONTAŻU

Narzędzia potrzebne do montażu




R-8 St.




K- 32 St.




D-15 St.




G- 14St.




S-6 St.
4x27




U-3 St.



N- 32 St.



J-3 St.




Z-24 St.
3,5x16



E-80 St.



B-47 St.



Y-1 St.

