










system PORTOS


P-05




Narzędzia potrzebne do montażu




R-2 St.




A-2 St.




N-24 St.




K-10 St.
4x30




G-20 St.




S-10 St.
4x27




U-5 St.




H-2 St.



J-5 Kpl.




E-80 St.



T-24 St.



B-44 St.





Y-1 St.




Z-60 St.
3,5x16




I



II



III



IV

